



powercords headunit checklist

Radio type:

Article number:

AIWA

AIWA CTR	SMK207903005
AIWA CTX	SMK207903005

ALPINE

ALPINE 7513	SMK207906015
ALPINE 7513L/M	SMK207906010
ALPINE 7514	SMK207906015
ALPINE 7514/L/M	SMK207906010
ALPINE 7515	SMK207906015
ALPINE 7515R	SMK207906010
ALPINE 7521	SMK207906015
ALPINE 77521R	SMK207906010
ALPINE 7804M	SMK207906010
ALPINE 7805M	SMK207906010
ALPINE 7805M	SMK207906015
ALPINE 7807R	SMK207906010
ALPINE 7807R	SMK207906015
ALPINE 7817LM	SMK207906015
ALPINE 7818R	SMK207906010
ALPINE 7894	SMK207906015
ALPINE 900R/RB	SMK207906020
ALPINE CDA-7842	SMK207906015
ALPINE CDA-7842R	SMK207906010
ALPINE CDA-7850	SMK207906015
ALPINE CDA-7850R	SMK207906010
ALPINE CDA-7852	SMK207906015
ALPINE CDA-7852R	SMK207906010
ALPINE CDA7865R	SMK207906010
ALPINE CDA-7873R	SMK207906010
ALPINE CDA-7875RB	SMK207906010
ALPINE CDA-7876RB	SMK207906010
ALPINE CDA-7878R	SMK207906010
ALPINE CDA-7893R	SMK207906010
ALPINE CDA-7894RB	SMK207906010
ALPINE CDA-7944R	SMK207906010
ALPINE CDA-7944R	SMK207906015
ALPINE CDA-7990R	SMK207906010
ALPINE CDA-7998R	SMK207906010
ALPINE CDA-9811R	SMK207906010
ALPINE CDA-9812/3RR	SMK207906020
ALPINE CDA-9812/5RB	SMK207906020
ALPINE CDA-9812RB/RR	SMK207906010
ALPINE CDA-9813RR	SMK207906010
ALPINE CDA-9815RB	SMK207906010
ALPINE CDA-9822/35RR	SMK207906020
ALPINE CDA-9830/31R	SMK207906020
ALPINE CDA-9830R	SMK207906010
ALPINE CDA-9831R	SMK207906010
ALPINE CDA-9833/R	SMK207906010
ALPINE CDA-9835R	SMK207906010
ALPINE CDE-228	SMK207906010

Radio type:

Article number:

ALPINE CDE-228	SMK207906015
ALPINE CDE-7820	SMK207906010
ALPINE CDE-7820	SMK207906015
ALPINE CDE-7853R	SMK207906010
ALPINE CDE-7854R/RM	SMK207906010
ALPINE CDE-7854R/RM	SMK207906015
ALPINE CDE-7855RB	SMK207906010
ALPINE CDE-7855RG	SMK207906015
ALPINE CDE-7860R	SMK207906010
ALPINE CDE-9801R	SMK207906010
ALPINE CDE-9802RB	SMK207906010
ALPINE CDE-9821R/RM	SMK207906010
ALPINE CDE-9822RB	SMK207906010
ALPINE CDE-9823R/RR	SMK207906020
ALPINE CDE-9825RB	SMK207906020
ALPINE CDE-9827R/RM/RR	SMK207906020
ALPINE CDE-9828RB	SMK207906010
ALPINE CDE-9828RB	SMK207906020
ALPINE CDE-9872R/RM/RR	SMK207906010
ALPINE CDM_9823R/RR	SMK207906010
ALPINE CDM-7807R	SMK207906010
ALPINE CDM-7838R	SMK207906010
ALPINE CDM-7838R	SMK207906015
ALPINE CDM-7856RB	SMK207906010
ALPINE CDM-7858RB	SMK207906010
ALPINE CDM-7859RB	SMK207906010
ALPINE CDM-7861R	SMK207906010
ALPINE CDM-7871R	SMK207906010
ALPINE CDM-9803R/RB/RM/RR	SMK207906010
ALPINE CDM-9805R	SMK207906010
ALPINE CDM-9807RB	SMK207906010
ALPINE CDM-9821R/RM	SMK207906010
ALPINE CDM-9822RB	SMK207906010
ALPINE CDM-9825RB	SMK207906010
ALPINE CDX-7872R	SMK207906010
ALPINE CDX-7874RB	SMK207906010
ALPINE CTM-1503R	SMK207906010
ALPINE CVA-1003R	SMK207906010
ALPINE CVA-1003R	SMK207906020
ALPINE IVA D-300/10 R/B	SMK207906020
ALPINE NVA-N033R	SMK207906020
ALPINE TDA-7561	SMK207906015
ALPINE TDA-7561R	SMK207906010
ALPINE TDA-7562	SMK207906015
ALPINE TDA-7562R	SMK207906010
ALPINE TDA-7570	SMK207906015
ALPINE TDA-7570R	SMK207906010
ALPINE TDA-7572R	SMK207906010
ALPINE TDA-7572R	SMK207906015
ALPINE TDA-7587R	SMK207906010
ALPINE TDA-7588RB	SMK207906010
ALPINE TDA-7592R	SMK207906010
ALPINE TDA-7592R	SMK207906020



powercords headunit checklist

Radio type:	Article number:
ALPINE TDM-7522M	SMK207906010
ALPINE TDM-7522M	SMK207906015
ALPINE TDM-7533M	SMK207906010
ALPINE TDM-7533M	SMK207906015
ALPINE TDM-7544R	SMK207906010
ALPINE TDM-7544R	SMK207906015
ALPINE TDM-7555R	SMK207906010
ALPINE TDM-7555R	SMK207906015
ALPINE TDM-7574R	SMK207906015
ALPINE TDM-7574R/RM	SMK207906010
ALPINE TDM-7574RM	SMK207906015
ALPINE TDM-7575B	SMK207906015
ALPINE TDM-7580R/RM	SMK207906010
ALPINE TDM-7581RB	SMK207906010
ALPINE TDM-7583RB	SMK207906010
ALPINE TDM-7585R	SMK207906010
ALPINE TDM-7590R	SMK207906010
ALPINE TDM-9501R/RM	SMK207906010
ALPINE TDM-9501R/RM	SMK207906020
ALPINE TDM-9503R	SMK207906010
ALPINE TDM-9503R	SMK207906020
ALPINE TDM-9505RB	SMK207906010
ALPINE TDM-9505RB	SMK207906020

CLARION

CLARION models w. 12-pin connectors	SMK207915010
CLARION CRX121RM	SMK207915005
CLARION CRX123RM	SMK207915005
CLARION CRX97RM	SMK207915005
CLARION DRB5175	SMK207915005
CLARION RX87RM	SMK207915005

JVC

JVC 120E	SMK207924020
JVC 120G	SMK207924020
JVC 220E	SMK207924020
JVC 220G	SMK207924020
JVC 33E	SMK207924020
JVC 33G	SMK207924020
JVC 440G	SMK207924020
JVC KD-AVX1E	SMK207924010
JVC KD-DV5000	SMK207924010
JVC KD-DV5101	SMK207924010
JVC KD-DV6101	SMK207924010
JVC KD-FX all models	SMK207924015
JVC KD-FX30R	SMK207924005
JVC KD-FX50R	SMK207924005
JVC KD-LH(X) '04	SMK207924010
JVC KD-LX/SH(X) '01>	SMK207924010
JVC KD-LX10R	SMK207924005
JVC KD-LX12R	SMK207924005
JVC KD-LX3R	SMK207924010

Radio type:	Article number:
JVC KD-M2900R	SMK207924005
JVC KD-MD all models	SMK207924015
JVC KD-MX3000R	SMK207924010
JVC KD-NX901	SMK207924010
JVC KD-S all models	SMK207924015
JVC KD-S5050	SMK207924010
JVC KD-S550	SMK207924010
JVC KD-S611	SMK207924005
JVC KD-S621	SMK207924005
JVC KD-SC500	SMK207924010
JVC KD-SCGT '02>	SMK207924010
JVC KD-SX '01>	SMK207924005
JVC KD-SX100R	SMK207924010
JVC KRST404	SMK207924025
JVC KS-F/FX '01>	SMK207924005
JVC KS-R370	SMK207924020
JVC LS-R440E	SMK207924020

KENWOOD

KENWOOD KDC-2027SA	SMK207930015
KENWOOD KDC-2027SG	SMK207930015
KENWOOD KDC-2031SA/SG	SMK207930015
KENWOOD KDC-2092R	SMK207930015
KENWOOD KDC-3021G/A	SMK207930015
KENWOOD KDC-3021SA/SG	SMK207930015
KENWOOD KDC-3024G/A	SMK207930015
KENWOOD KDC-3027G/A	SMK207930015
KENWOOD KDC-3031G/A	SMK207930015
KENWOOD KDC-306	SMK207930015
KENWOOD KDC-307	SMK207930015
KENWOOD KDC-3080RG	SMK207930015
KENWOOD KDC-3090RG	SMK207930015
KENWOOD KDC-358DAB	SMK207930015
KENWOOD KDC-4021V	SMK207930015
KENWOOD KDC-4024V	SMK207930015
KENWOOD KDC-4027V	SMK207930015
KENWOOD KDC-4050LG	SMK207930015
KENWOOD KDC-4060RG	SMK207930015
KENWOOD KDC-4070RG/RV	SMK207930015
KENWOOD KDC-4080R/RV	SMK207930015
KENWOOD KDC-4090R	SMK207930015
KENWOOD KDC-4590R	SMK207930015
KENWOOD KDC-5021R	SMK207930015
KENWOOD KDC-5024V	SMK207930015
KENWOOD KDC-5027	SMK207930015
KENWOOD KDC-5040N	SMK207930015
KENWOOD KDC-5050RG	SMK207930015
KENWOOD KDC-506	SMK207930015
KENWOOD KDC-5060R	SMK207930015
KENWOOD KDC-5070R	SMK207930015
KENWOOD KDC-5080R	SMK207930015
KENWOOD KDC-5090R/B	SMK207930015



powercords headunit checklist

Radio type:

Article number:

KENWOOD KDC-6021R	SMK207930015
KENWOOD KDC-6024	SMK207930015
KENWOOD KDC-6050R/RC	SMK207930015
KENWOOD KDC-6060R	SMK207930015
KENWOOD KDC-6070R	SMK207930015
KENWOOD KDC-6080R/RV	SMK207930015
KENWOOD KDC-6090R	SMK207930015
KENWOOD KDC-6090R	SMK207930015
KENWOOD KDC-7021R/SE	SMK207930015
KENWOOD KDC-7024/7	SMK207930015
KENWOOD KDC-7040R	SMK207930015
KENWOOD KDC-7050R	SMK207930015
KENWOOD KDC-7060R	SMK207930015
KENWOOD KDC-7070R/RDS	SMK207930015
KENWOOD KDC-7080R/RV	SMK207930015
KENWOOD KDC-7090R	SMK207930015
KENWOOD KDC-757W/C	SMK207930015
KENWOOD KDC-8021R	SMK207930015
KENWOOD KDC-8024	SMK207930015
KENWOOD KDC-8040R	SMK207930015
KENWOOD KDC-8060R	SMK207930015
KENWOOD KDC-8070R/RW	SMK207930015
KENWOOD KDC-8080R	SMK207930015
KENWOOD KDC-8090R	SMK207930015
KENWOOD KDC-9050R	SMK207930015
KENWOOD KDC-9090R	SMK207930015
KENWOOD KDC-B7021R	SMK207930015
KENWOOD KDC-M4524(G)	SMK207930015
KENWOOD KDC-M6021G	SMK207930015
KENWOOD KDC-M6024(G)	SMK207930015
KENWOOD KDC-M7024	SMK207930015
KENWOOD KDC-M9021(R)	SMK207930015
KENWOOD KDC-MP6090R	SMK207930015
KENWOOD KDC-MV6521R	SMK207930015
KENWOOD KDC-PS0590R	SMK207930015
KENWOOD KDC-PS9060R	SMK207930015
KENWOOD KDC-PS9070R	SMK207930015
KENWOOD KDC-PS9080R	SMK207930015
KENWOOD KDC-PS9524	SMK207930015
KENWOOD KDC-PSW9521(R)	SMK207930015
KENWOOD KDC-PSW9524	SMK207930015
KENWOOD KDC-PSW9527	SMK207930015
KENWOOD KDC-PSW9531	SMK207930015
KENWOOD KDC-V6090R	SMK207930015
KENWOOD KDC-V6524	SMK207930015
KENWOOD KDC-V7090R	SMK207930015
KENWOOD KDC-V7521R	SMK207930015
KENWOOD KDC-W4031A	SMK207930015
KENWOOD KDC-W409	SMK207930015
KENWOOD KDC-W4527(G)	SMK207930015
KENWOOD KDC-W4531	SMK207930015
KENWOOD KDC-W6027	SMK207930015
KENWOOD KDC-W6027	SMK207930015

Radio type:

Article number:

KENWOOD KDC-W6031	SMK207930015
KENWOOD KDC-W7027	SMK207930015
KENWOOD KDC-W7031	SMK207930015
KENWOOD KDC-W707	SMK207930015
KENWOOD KDC-W7531	SMK207930015
KENWOOD KDC-W8027	SMK207930015
KENWOOD KDC-W808	SMK207930015
KENWOOD KDC-W8531	SMK207930015
KENWOOD KDC-W9027	SMK207930015
KENWOOD KMD-671R	SMK207930015
KENWOOD KMD-673R	SMK207930015
KENWOOD KMD-870R	SMK207930015
KENWOOD KMD-PS671R	SMK207930015
KENWOOD KMD-PS870R	SMK207930015
KENWOOD KMD-PS970R	SMK207930015
KENWOOD KMD-PS971R	SMK207930015
KENWOOD KRC-1054R	SMK207930020
KENWOOD KRC-11/12/13R	SMK207930015
KENWOOD KRC-150N	SMK207930015
KENWOOD KRC-151/2LG	SMK207930015
KENWOOD KRC-1550N	SMK207930010
KENWOOD KRC-155N	SMK207930010
KENWOOD KRC-1570N/R/L/D	SMK207930015
KENWOOD KRC157L/D	SMK207930015
KENWOOD KRC157N/R	SMK207930015
KENWOOD KRC-158RG	SMK207930015
KENWOOD KRC-159G	SMK207930015
KENWOOD KRC-16/17/36R	SMK207930015
KENWOOD KRC-177RG	SMK207930015
KENWOOD KRC-178RG	SMK207930015
KENWOOD KRC-179RC	SMK207930015
KENWOOD KRC-191G/A	SMK207930015
KENWOOD KRC-194G	SMK207930015
KENWOOD KRC-254D/N	SMK207930020
KENWOOD KRC-255N	SMK207930010
KENWOOD KRC-2560N/R	SMK207930015
KENWOOD KRC-256L/D	SMK207930015
KENWOOD KRC-256N/R	SMK207930015
KENWOOD KRC-2570RL/RD	SMK207930015
KENWOOD KRC-257R/RL	SMK207930015
KENWOOD KRC-258LG	SMK207930015
KENWOOD KRC-259R	SMK207930015
KENWOOD KRC-277G	SMK207930015
KENWOOD KRC-278RG	SMK207930015
KENWOOD KRC-279RC	SMK207930015
KENWOOD KRC-291R	SMK207930015
KENWOOD KRC-294G/A	SMK207930015
KENWOOD KRC-354C/D/L/N	SMK207930020
KENWOOD KRC-355R/RL	SMK207930005
KENWOOD KRC-356R/N/L/D	SMK207930015
KENWOOD KRC-357R/N/L/D	SMK207930015
KENWOOD KRC-358RG	SMK207930015
KENWOOD KRC-358RG	SMK207930015



powercords headunit checklist

Radio type:

Article number:

KENWOOD KRC-377R	SMK207930015
KENWOOD KRC-378R	SMK207930015
KENWOOD KRC-391R	SMK207930015
KENWOOD KRC-394	SMK207930015
KENWOOD KRC-454L/D	SMK207930020
KENWOOD KRC-456R/RF/RL	SMK207930015
KENWOOD KRC-457RL	SMK207930015
KENWOOD KRC-458LG	SMK207930015
KENWOOD KRC-459R	SMK207930015
KENWOOD KRC-477R/RV	SMK207930015
KENWOOD KRC-478R/RV	SMK207930015
KENWOOD KRC-554L/D	SMK207930015
KENWOOD KRC-556R/RL	SMK207930015
KENWOOD KRC-557N/L	SMK207930015
KENWOOD KRC-557N/L	SMK207930020
KENWOOD KRC-558RG	SMK207930015
KENWOOD KRC-559R	SMK207930015
KENWOOD KRC-577R	SMK207930015
KENWOOD KRC-578R	SMK207930015
KENWOOD KRC-579R/B	SMK207930015
KENWOOD KRC-591(R/V)	SMK207930015
KENWOOD KRC-594/7	SMK207930015
KENWOOD KRC-654RD/RL	SMK207930020
KENWOOD KRC-656R/RL	SMK207930015
KENWOOD KRC-657R/RL	SMK207930015
KENWOOD KRC-658R	SMK207930015
KENWOOD KRC-659R	SMK207930015
KENWOOD KRC-677R	SMK207930015
KENWOOD KRC-678R/RV	SMK207930015
KENWOOD KRC-679R	SMK207930015
KENWOOD KRC-691R	SMK207930015
KENWOOD KRC-694	SMK207930015
KENWOOD KRC-754L/D	SMK207930015
KENWOOD KRC-755R	SMK207930015
KENWOOD KRC-755R	SMK207930005
KENWOOD KRC-757R/RL/W/C	SMK207930015
KENWOOD KRC-757W/C	SMK207930020
KENWOOD KRC-758R	SMK207930015
KENWOOD KRC-758R	SMK207930005
KENWOOD KRC-759R	SMK207930015
KENWOOD KRC-777R	SMK207930015
KENWOOD KRC-778R/RV	SMK207930015
KENWOOD KRC-779R	SMK207930015
KENWOOD KRC-791R	SMK207930015
KENWOOD KRC-794	SMK207930015
KENWOOD KRC-854RD/RL	SMK207930020
KENWOOD KRC-856R	SMK207930015
KENWOOD KRC-857R/W/RL	SMK207930015
KENWOOD KRC-858C/R/W	SMK207930015
KENWOOD KRC-858C/R/W	SMK207930015
KENWOOD KRC-859R/W/C	SMK207930015
KENWOOD KRC-877R/W	SMK207930015
KENWOOD KRC-878R	SMK207930015
KENWOOD KRC-954R	SMK207930005
KENWOOD KRC-956R/RL	SMK207930015
KENWOOD KRC-957R/RL/SCR	SMK207930015

Radio type:

Article number:

KENWOOD KRC-958R	SMK207930015
KENWOOD KRC-977R	SMK207930015
KENWOOD KRC-992R	SMK207930015
KENWOOD KRC-PS1077R	SMK207930015
KENWOOD KRC-PS959R	SMK207930015
KENWOOD KRC-PS978R	SMK207930015
KENWOOD KRC-PS979R	SMK207930015
KENWOOD KRC-V679R	SMK207930015
KENWOOD KRC-V791R	SMK207930015
KENWOOD KRC-V879R	SMK207930015
KENWOOD KRC-Z638	SMK207930015
KENWOOD KRC-Z838W	SMK207930015

PANASONIC

PANASONIC models w. 12-pin connectors	SMK207939015
PANASONIC models w. 16-pin connectors	SMK207939020
PANASONIC CQ-CRD115	SMK207945010
PANASONIC CQ-D80EN	SMK207939005
PANASONIC CQ-DFX/301	SMK207945010
PANASONIC CQ-DFX/600N	SMK207945010
PANASONIC CQ-DFX100N	SMK207945010
PANASONIC CQ-DFX201	SMK207945010
PANASONIC CQ-DFX355	SMK207945010
PANASONIC CQ-DFX400N (G)	SMK207945010
PANASONIC CQ-DFX444 (G)	SMK207945010
PANASONIC CQ-DFX501	SMK207945010
PANASONIC CQ-DFX527N	SMK207945010
PANASONIC CQ-DFX555N	SMK207945010
PANASONIC CQ-DFX601	SMK207945010
PANASONIC CQ-DFX666	SMK207945010
PANASONIC CQ-DFX700N	SMK207945010
PANASONIC CQ-DFX701	SMK207945010
PANASONIC CQ-DFX751	SMK207945010
PANASONIC CQ-DFX777	SMK207945010
PANASONIC CQ-DFX800N	SMK207945010
PANASONIC CQ-DFX888	SMK207945010
PANASONIC CQ-DPG55	SMK207939005
PANASONIC CQ-DRX900N	SMK207945010
PANASONIC CQ-FRX920N	SMK207945010
PANASONIC CQ-FX/66	SMK207945010
PANASONIC CQ-FX220N	SMK207945010
PANASONIC CQ-FX321	SMK207945010
PANASONIC CQ-FX35	SMK207945010
PANASONIC CQ-FX420N	SMK207945010
PANASONIC CQ-FX421	SMK207945010
PANASONIC CQ-FX44(G)	SMK207945010
PANASONIC CQ-FX45RD	SMK207939005
PANASONIC CQ-FX55	SMK207945010
PANASONIC CQ-FX620N	SMK207945010
PANASONIC CQ-FX720N	SMK207945010
PANASONIC CQ-FX721	SMK207945010
PANASONIC CQ-FX75	SMK207945010
PANASONIC CQ-FX77	SMK207945010



powercords headunit checklist

Radio type: Article number:

PANASONIC CQ-FX820N	SMK207945010
PANASONIC CQ-FX85RD	SMK207939005
PANASONIC CQ-FX88	SMK207945010
PANASONIC CQ-FX95	SMK207945010
PANASONIC CQ-MR303	SMK207945010
PANASONIC CQ-MR355	SMK207945010
PANASONIC CQ-MR505N	SMK207945010
PANASONIC CQ-MR555	SMK207945010
PANASONIC CQ-MR707	SMK207945010
PANASONIC CQ-P200	SMK207939005
PANASONIC CQ-P400	SMK207939005
PANASONIC CQ-P500	SMK207939005
PANASONIC CQ-P650	SMK207939005
PANASONIC CQ-P700	SMK207939005
PANASONIC CQ-P735	SMK207939005
PANASONIC CQ-P750	SMK207939005
PANASONIC CQ-P830 (W)	SMK207939005
PANASONIC CQ-P855 (W)	SMK207939005
PANASONIC CQ-P920	SMK207939005
PANASONIC CQ-P930	SMK207939005
PANASONIC CQ-R113GLEN	SMK207939005
PANASONIC CQ-R115	SMK207939005
PANASONIC CQ-R220G	SMK207939005
PANASONIC CQ-R305	SMK207939005
PANASONIC CQ-R35	SMK207939005
PANASONIC CQ-R525	SMK207939005
PANASONIC CQ-RD113N	SMK207939005
PANASONIC CQ-RD115N	SMK207939005
PANASONIC CQ-RD310	SMK207939005
PANASONIC CQ-RD320	SMK207939005
PANASONIC CQ-RD324	SMK207945010
PANASONIC CQ-RD325	SMK207945010
PANASONIC CQ-RD325N	SMK207939005
PANASONIC CQ-RD33N	SMK207939005
PANASONIC CQ-RD40	SMK207939005
PANASONIC CQ-RD430	SMK207945010
PANASONIC CQ-RD435	SMK207939005
PANASONIC CQ-RD445	SMK207939005
PANASONIC CQ-RD45	SMK207939005
PANASONIC CQ-RD50	SMK207939005
PANASONIC CQ-RD525	SMK207939005
PANASONIC CQ-RD535	SMK207939005
PANASONIC CQ-RD545	SMK207939005
PANASONIC CQ-RD555	SMK207939005
PANASONIC CQ-RD565	SMK207939005
PANASONIC CQ-RD575	SMK207939005
PANASONIC CQ-RD585	SMK207939005
PANASONIC CQ-RD595	SMK207939005
PANASONIC CQ-RD70	SMK207939005
PANASONIC CQ-RD75	SMK207939005
PANASONIC CQ-RD810	SMK207939005
PANASONIC CQ-RD811	SMK207939005
PANASONIC CQ-RD815 (W)	SMK207939005

Radio type: Article number:

PANASONIC CQ-RD825 (W)	SMK207939005
PANASONIC CQ-RD900	SMK207939005
PANASONIC CQ-RD905	SMK207945010
PANASONIC CQ-RD915	SMK207945010
PANASONIC CQ-RD925	SMK207945010
PANASONIC CQ-RD95	SMK207939005
PANASONIC CQ-RD965	SMK207945010
PANASONIC CQ-SRK7000N	SMK207945010

PIONEER

PIONEER DEH-1300/10R	SMK207945025
PIONEER DEH-1310	SMK207945040
PIONEER DEH-1330	SMK207945025
PIONEER DEH-1400R	SMK207945025
PIONEER DEH-1430RB	SMK207945025
PIONEER DEH-1500/30R	SMK207945075
PIONEER DEH-1600R/RB	SMK207945075
PIONEER DEH-1630R	SMK207945075
PIONEER DEH-1700/30R	SMK207945075
PIONEER DEH-2000	SMK207945040
PIONEER DEH-2000/30R	SMK207945015
PIONEER DEH-2030	SMK207945040
PIONEER DEH-2100	SMK207945040
PIONEER DEH-2100/30R	SMK207945015
PIONEER DEH-2130	SMK207945040
PIONEER DEH-2300/30R	SMK207945025
PIONEER DEH-2330RB	SMK207945040
PIONEER DEH-2330RB	SMK207945040
PIONEER DEH-2330R-B	SMK207945025
PIONEER DEH-2430/60R	SMK207945025
PIONEER DEH-2700R	SMK207945075
PIONEER DEH-3100	SMK207945040
PIONEER DEH-3100/30R	SMK207945015
PIONEER DEH-3130	SMK207945040
PIONEER DEH-3300/30R	SMK207945025
PIONEER DEH-3400R	SMK207945025
PIONEER DEH-344R	SMK207945055
PIONEER DEH-345R	SMK207945055
PIONEER DEH-3700/30MP	SMK207945075
PIONEER DEH-4000R	SMK207945015
PIONEER DEH-425R	SMK207945055
PIONEER DEH-435R	SMK207945055
PIONEER DEH-4700MP/B	SMK207945075
PIONEER DEH-5200	SMK207945035
PIONEER DEH-5202	SMK207945035
PIONEER DEH-524R	SMK207945055
PIONEER DEH-525R	SMK207945055
PIONEER DEH-534R/W	SMK207945010
PIONEER DEH-535R/W	SMK207945010
PIONEER DEH-635R/W	SMK207945010
PIONEER DEH-5800	SMK207945035
PIONEER DEH-624R	SMK207945055
PIONEER DEH-625R	SMK207945055



powercords headunit checklist

Radio type:	Article number:	Radio type:	Article number:
PIONEER DEH-670SDK	SMK207945005	PIONEER DEH-P715RDS	SMK207945060
PIONEER DEH-725R	SMK207945010	PIONEER DEH-P725UC	SMK207945010
PIONEER DEH-8000	SMK207945035	PIONEER DEH-P7300R	SMK207945025
PIONEER DEH-8300	SMK207945035	PIONEER DEH-P735R	SMK207945010
PIONEER DEH-8500RDS	SMK207945035	PIONEER DEH-P735UC	SMK207945010
PIONEER DEH-B4100R	SMK207945015	PIONEER DEH-P7400MP	SMK207945025
PIONEER DEH-M77	SMK207945035	PIONEER DEH-P7400MP	SMK207945035
PIONEER DEH-M77	SMK207945060	PIONEER DEH-P7500MP	SMK207945075
PIONEER DEH-M940	SMK207945035	PIONEER DEH-P7700MP	SMK207945075
PIONEER DEH-M940	SMK207945060	PIONEER DEH-P8000R	SMK207945010
PIONEER DEH-M970	SMK207945035	PIONEER DEH-P8100R	SMK207945010
PIONEER DEH-M970	SMK207945060	PIONEER DEH-P813ES	SMK207945010
PIONEER DEH-M980	SMK207945035	PIONEER DEH-P815R	SMK207945010
PIONEER DEH-M980(RDS/DSP)	SMK207945060	PIONEER DEH-P820RDS	SMK207945010
PIONEER DEH-M990RDS/DSP	SMK207945060	PIONEER DEH-P825R	SMK207945010
PIONEER DEH-MDSP	SMK207945035	PIONEER DEH-P835	SMK207945010
PIONEER DEH-MRDS	SMK207945035	PIONEER DEH-P8400MP	SMK207945010
PIONEER DEH-P1590R	SMK207945075	PIONEER DEH-P875R	SMK207945010
PIONEER DEH-P2500R/RB	SMK207945075	PIONEER DEH-P9000R	SMK207945010
PIONEER DEH-P2530R	SMK207945030	PIONEER DEH-P9100R	SMK207945010
PIONEER DEH-P2530R	SMK207945075	PIONEER DEH-P9300R	SMK207945010
PIONEER DEH-P2600R	SMK207945075	PIONEER DEH-P9400MP	SMK207945010
PIONEER DEH-P-3000	SMK207945040	PIONEER DEH-P945R	SMK207945010
PIONEER DEH-P3000R	SMK207945015	PIONEER DEX-2000R	SMK207945015
PIONEER DEH-P3100/10	SMK207945015	PIONEER DEX-FH-P4000R	SMK207945010
PIONEER DEH-P-3110	SMK207945040	PIONEER DEX-FHP6600R	SMK207945010
PIONEER DEH-P3300/30R	SMK207945025	PIONEER DEX-P77R	SMK207945010
PIONEER DEH-P3500/90MP	SMK207945075	PIONEER DEX-P820R	SMK207945010
PIONEER DEH-P3600/30MP	SMK207945075	PIONEER DEX-P88R	SMK207945010
PIONEER DEH-P3600MPB	SMK207945075	PIONEER DEX-P99R	SMK207945010
PIONEER DEH-P-4100R	SMK207945040	PIONEER KEH-1100/50	SMK207945020
PIONEER DEH-P-4300RB	SMK207945040	PIONEER KEH-1200	SMK207945020
PIONEER DEH-P4300R-B	SMK207945025	PIONEER KEH-1300(K/SDK)	SMK207945020
PIONEER DEH-P4400R/RB	SMK207945025	PIONEER KEH-1311	SMK207945020
PIONEER DEH-P443R	SMK207945010	PIONEER KEH-1400	SMK207945020
PIONEER DEH-P4500MP	SMK207945075	PIONEER KEH-1450	SMK207945020
PIONEER DEH-P5100R/RB	SMK207945050	PIONEER KEH-1500/30	SMK207945020
PIONEER DEH-P544R	SMK207945010	PIONEER KEH-1700/30	SMK207945020
PIONEER DEH-P545R	SMK207945010	PIONEER KEH-1800R	SMK207945020
PIONEER DEH-P5500/30MP	SMK207945075	PIONEER KEH-1900/30R	SMK207945020
PIONEER DEH-P5600/30MP	SMK207945075	PIONEER KEH-1940R	SMK207945020
PIONEER DEH-P5700MP	SMK207945075	PIONEER KEH-2000	SMK207945005
PIONEER DEH-P6000R	SMK207945050	PIONEER KEH-2100R	SMK207945020
PIONEER DEH-P6100R	SMK207945050	PIONEER KEH-2300R	SMK207945020
PIONEER DEH-P625UC	SMK207945010	PIONEER KEH-2400R	SMK207945020
PIONEER DEH-P6300R	SMK207945025	PIONEER KEH-2500	SMK207945005
PIONEER DEH-P6400R	SMK207945025	PIONEER KEH-2500/30R	SMK207945045
PIONEER DEH-P645R/W	SMK207945010	PIONEER KEH-2500R	SMK207945030
PIONEER DEH-P6500MP	SMK207945075	PIONEER KEH-2600(SDK)	SMK207945065
PIONEER DEH-P6700MP	SMK207945075	PIONEER KEH-2700/30R	SMK207945020
PIONEER DEH-P7000R(-W)	SMK207945050	PIONEER KEH-3600(SDK)	SMK207945065
PIONEER DEH-P705RDS	SMK207945060	PIONEER KEH-415	SMK207945065
PIONEER DEH-P7100R-W	SMK207945050	PIONEER KEH-5200RDS	SMK207945060



powercords headunit checklist

Radio type: Article number:

PIONEER KEH-5202RDS	SMK207945060
PIONEER KEH-5300(SDK)	SMK207945005
PIONEER KEH-5400RDS	SMK207945005
PIONEER KEH-5700/30R	SMK207945020
PIONEER KEH-5800RDS	SMK207945060
PIONEER KEH-M2000	SMK207945005
PIONEER KEH-M2500	SMK207945005
PIONEER KEH-M3500	SMK207945005
PIONEER KEH-M4000	SMK207945005
PIONEER KEH-M4500	SMK207945005
PIONEER KEH-M6500	SMK207945005
PIONEER KEH-M7200	SMK207945005
PIONEER KEH-M7250	SMK207945005
PIONEER KEH-M7300	SMK207945005
PIONEER KEH-M74000RDS	SMK207945005
PIONEER KEH-M8000	SMK207945060
PIONEER KEH-M8300	SMK207945060
PIONEER KEH-M8500	SMK207945060
PIONEER KEH-M9100	SMK207945060
PIONEER KEH-M9300	SMK207945060
PIONEER KEH-M9500	SMK207945060
PIONEER KEH-M9500RDS	SMK207945060
PIONEER KEH-MRDS	SMK207945035
PIONEER KEH-P1010/13R	SMK207945070
PIONEER KEH-P1032/33	SMK207945070
PIONEER KEH-P11R	SMK207945065
PIONEER KEH-P2030/33R	SMK207945070
PIONEER KEH-P2800R	SMK207945020
PIONEER KEH-P3400	SMK207945020
PIONEER KEH-P3600/30R	SMK207945045
PIONEER KEH-P3600R	SMK207945030
PIONEER KEH-P3630R	SMK207945030
PIONEER KEH-P3700/30R	SMK207945020
PIONEER KEH-P4000	SMK207945065
PIONEER KEH-P4010	SMK207945030
PIONEER KEH-P4010	SMK207945045
PIONEER KEH-P4011	SMK207945030
PIONEER KEH-P4020/23R	SMK207945070
PIONEER KEH-P4300R	SMK207945020
PIONEER KEH-P4400R	SMK207945020
PIONEER KEH-P4500R	SMK207945020
PIONEER KEH-P4530R	SMK207945020
PIONEER KEH-P4600R	SMK207945030
PIONEER KEH-P4600R	SMK207945045
PIONEER KEH-P4610R	SMK207945030
PIONEER KEH-P4610R	SMK207945045
PIONEER KEH-P4630R	SMK207945030
PIONEER KEH-P4630R	SMK207945045
PIONEER KEH-P4700R	SMK207945020
PIONEER KEH-P4730R	SMK207945020
PIONEER KEH-P5000	SMK207945065
PIONEER KEH-P5010R	SMK207945030
PIONEER KEH-P5010R	SMK207945045

Radio type: Article number:

PIONEER KEH-P5700R	SMK207945020
PIONEER KEH-P6000RDS	SMK207945060
PIONEER KEH-P6010R	SMK207945030
PIONEER KEH-P6010R	SMK207945045
PIONEER KEH-P6020R/RB	SMK207945025
PIONEER KEH-P6400R	SMK207945010
PIONEER KEH-P6800R	SMK207945010
PIONEER KEH-P6900R	SMK207945010
PIONEER KEH-P7000RDS	SMK207945060
PIONEER KEH-P7020/R	SMK207945025
PIONEER KEH-P7025R	SMK207945025
PIONEER KEH-P7400R	SMK207945010
PIONEER KEH-P7600R	SMK207945010
PIONEER KEH-P7900R	SMK207945010
PIONEER KEH--8010R	SMK207945015
PIONEER KEH-P8015	SMK207945015
PIONEER KEH-P8015R	SMK207945040
PIONEER KEH-P80210	SMK207945040
PIONEER KEH-P8200RDS	SMK207945010
PIONEER KEH-P8400R	SMK207945010
PIONEER KEH-P8600RDS	SMK207945010
PIONEER KEH-P8600R-W	SMK207945010
PIONEER KEH-P8800R-V	SMK207945010
PIONEER KEH-P8900RW	SMK207945010
PIONEER KEH-P9200RDS	SMK207945010
PIONEER KEH-P9700R-W	SMK207945010
PIONEER KEX-P8200RDS	SMK207945010
PIONEER MEH-P7100R	SMK207945010
PIONEER MEH-P7300R	SMK207945010
PIONEER MEH-P9000R	SMK207945010
PIONEER MEH-P9100R	SMK207945010

SONY

SONY all models with 13-pin connectors	SMK207954015
SONY CDX-2500R	SMK207954005
SONY CDX-3000/02	SMK207954005
SONY CDX-3100/60	SMK207954005
SONY CDX-3150R	SMK207954005
SONY CDX-3180R	SMK207954005
SONY CDX-3180R	SMK207954005
SONY CDX-3250	SMK207954005
SONY CDX-4000R-RV	SMK207954005
SONY CDX-4100/60	SMK207954005
SONY CDX-4180R(W)	SMK207954005
SONY CDX-4180R(-W)	SMK207954005
SONY CDX-4250R	SMK207954005
SONY CDX-4270R	SMK207954005
SONY CDX-4850R	SMK207954005
SONY CDX-5000R-RV	SMK207954005
SONY CDX-5070RDS	SMK207954010
SONY CDX-5100RDS	SMK207954010
SONY CDX-5290RDS	SMK207954010
SONY CDX-5470RDS	SMK207954010



powercords headunit checklist

Radio type:

Article number:

SONY CDX-580R-V	SMK207954005
SONY CDX-5850R	SMK207954005
SONY CDX-600DSP	SMK207954010
SONY CDX-610R-V	SMK207954005
SONY CDX-650X-V	SMK207954005
SONY CDX-6850R	SMK207954005
SONY CDX-760/80R-V	SMK207954005
SONY CDX-7850R	SMK207954005
SONY CDX-8000RX	SMK207954005
SONY CDX-810R-V(W)	SMK207954005
SONY CDX-860R-V(W)	SMK207954005
SONY CDX-8850R	SMK207954005
SONY CDX-910R-V(W)	SMK207954005
SONY CDX-C490RDS	SMK207954010
SONY CDXC560R	SMK207954005
SONY CDXC580R	SMK207954005
SONY CDX-C90RDS	SMK207954010
SONY CDX-CA600X	SMK207954005
SONY CDX-CA650	SMK207954005
SONY CDX-CA680	SMK207954005
SONY CDX-CA650R/X/V	SMK207954005
SONY CDX-CA680/700X	SMK207954005
SONY CDX-CA750(R/X)	SMK207954005
SONY CDX-CA850R/MP	SMK207954005
SONY CDX-CA900	SMK207954005
SONY CDX-F5500	SMK207954005
SONY CDX-F5550	SMK207954005
SONY CDX-F7500	SMK207954005
SONY CDX-F7700	SMK207954005
SONY CDX-F7700	SMK207954005
SONY CDX-F7750(S)	SMK207954005
SONY CDX-L280	SMK207954005
SONY CDX-L350	SMK207954005
SONY CDX-L380	SMK207954005
SONY CDX-L400	SMK207954005
SONY CDX-L410	SMK207954005
SONY CDX-L420	SMK207954005
SONY CDX-L450	SMK207954005
SONY CDX-L480X	SMK207954005
SONY CDX-L550	SMK207954005
SONY CDX-L550X/V	SMK207954005
SONY CDX-L580X	SMK207954005
SONY CDX-L600X	SMK207954005
SONY CDX-M1000TF	SMK207954005
SONY CDX-M610R	SMK207954005
SONY CDX-M630R	SMK207954005
SONY CDX-M610R	SMK207954005
SONY CDX-M630R	SMK207954005
SONY CDX-M670R	SMK207954005
SONY CDX-M700R	SMK207954005
SONY CDX-M730R	SMK207954005
SONY CDX-M770R	SMK207954005
SONY CDX-M7850	SMK207954005

Radio type:

Article number:

SONY CDX-M800	SMK207954005
SONY CDX-M850MP	SMK207954005
SONY CDX-M8800	SMK207954005
SONY CDX-M9900	SMK207954005
SONY CDX-MDXC150R	SMK207954005
SONY CDX-MDXC5970R	SMK207954005
SONY CDX-MDXC6500R	SMK207954005
SONY CDX-MDXC670R	SMK207954005
SONY CDX-MDXC770R	SMK207954005
SONY CDX-MDXC790RDS	SMK207954005
SONY CDX-MDXC7970R	SMK207954005
SONY CDX-MDXC8900/70R	SMK207954005
SONY CDX-MEX5DI	SMK207954005
SONY CDX-MP30/40	SMK207954005
SONY CDX-MP70/80	SMK207954005
SONY CDX-R3000	SMK207954005
SONY CDX-R3300	SMK207954005
SONY CDX-R3350	SMK207954005
SONY CDX-R6750	SMK207954005
SONY CDX-S2000	SMK207954005
SONY CDX-S2050	SMK207954005
SONY CDX-S2250(S)	SMK207954005
SONY CDX-S470RDS	SMK207954005
SONY CDX-SR1300R	SMK207954005
SONY CDX-WXC570R	SMK207954005
SONY CDX-XR1800R	SMK207954005
SONY CDX-XR2200	SMK207954005
SONY CDX-XR3501MK2	SMK207954005
SONY CDX-XR3690	SMK207954005
SONY CDX-XR3700	SMK207954005
SONY CDX-XR4800/80RE	SMK207954005
SONY CDX-XR6600	SMK207954005
SONY CDX-XR6690	SMK207954005
SONY CDX-XR6700	SMK207954005
SONY MDXC-150RDS	SMK207954010
SONY MEX-1HD	SMK207954020
SONY XR-3310	SMK207954010
SONY XR-3501	SMK207954010
SONY XRC-100/101	SMK207954005
SONY XRC-110/111	SMK207954005
SONY XRC-180	SMK207954005
SONY XRC200	SMK207954010
SONY XRC-210(MK2)	SMK207954010
SONY XRC-220	SMK207954005
SONY XRC-2300R	SMK207954005
SONY XRC-290RDS	SMK207954005
SONY XRC-300RDS	SMK207954005
SONY XRC-410	SMK207954010
SONY XRC-500RDS	SMK207954005
SONY XRC-6210R	SMK207954005
SONY XRC-6220R	SMK207954005
SONY XRC-650RDS	SMK207954005
SONY XRC-700	SMK207954005



powercords headunit checklist

Radio type:

Article number:

SONY XRC-7200R	SMK207954005
SONY XRC-7220R	SMK207954005
SONY XRC-7500R-RX	SMK207954005
SONY XRC-750RDS	SMK207954005
SONY XRC-8100R	SMK207954005
SONY XRC-8220R	SMK207954005
SONY XRC-850RDS	SMK207954005
SONY XRC-900RDS	SMK207954005
SONY XRC-9100R	SMK207954005
SONY XR-CA200	SMK207954005
SONY XR-CA300	SMK207954005
SONY XR-CA370X	SMK207954005
SONY XR-CA670X	SMK207954005
SONY XR-CA400	SMK207954005
SONY XR-CA600	SMK207954005
SONY XR-CA600X/V	SMK207954005
SONY XRC-RDS420	SMK207954010
SONY XRC-RDS430	SMK207954010
SONY XRC-RDS450	SMK207954010
SONY XRC-RDS510	SMK207954010
SONY XRC-RDS540	SMK207954010
SONY XRC-RDS550	SMK207954010
SONY XRC-RDS620	SMK207954010
SONY XRC-RDS720	SMK207954010
SONY XR-L200	SMK207954005
SONY XR-RDS4740	SMK207954010
SONY XR-RDS4750	SMK207954010
SONY XR-RDS5520	SMK207954010
SONY XR-RDS5620	SMK207954010
SONY XR-RDS6440	SMK207954010
SONY XR-RDS6450	SMK207954010
SONY XR-RDS6650	SMK207954010
SONY XR-RDS6750	SMK207954010
SONY XT-CA800	SMK207954005